




Bottoms Up 3 Button TOUCHPAD V1 NAVIGATION OVERVIEW

START BOTTOM FILLING NOW

1 POWER ON/OFF THE DISPENSER

ON: Press the **LARGE** size button 1x.

OFF: Hold the **LARGE** size button for .5 seconds to power off.



2 PROGRAM SIZE

1. Hold down the size button you want to program.
2. While holding, set a vessel onto the tap.
3. Lift your finger off the button when the beer in the vessel reaches the desired fill level.

***If you lift finger off too soon you can press it again*




3 START/STOP

START: The flow of beer will automatically start once the vessel is pushed down onto the unit.

STOP: Press any one of the size buttons 1x to stop the pour in progress.

***Great for pouring samples or if you accidentally poured the wrong size*




4 DEFAULT POUR SIZE

Change between three different sizes with a push of a button. Sizes must already be programmed (Step 2).


After each pour, the touchpad returns to a default size.

MEDIUM is the pre-programmed default size. (See Pg. 2)



5 ERROR

If the error light is blinking, call Technical Support at (888) 618-0486 opt. 1 or email us at support@bottomsupbeer.com





Bottoms Up 3 Button TOUCHPAD V1 NAVIGATION OVERVIEW

ADDITIONAL FEATURES


6 PURGE MODE (FOR START UP/CLEANING)

Purge mode allows you to pull in or purge out beer from the line. Used when first firing up your taps, changing brands or cleaning your lines. To enter purge mode, be sure the touchpad is **TURNED ON** then press **SMALL** and **MEDIUM** button at the same time. You'll know you're in purge mode when all three LEDs lite up.

PRESS AT SAME TIME **S** **M** → **S** **M** **L**

Push the tap into the down position and press any size button to start the purge. Press any size button to stop.


Press the **SMALL** and **MEDIUM** button to exit purge mode.



7 SETTINGS MODE (CUSTOMIZE)

Settings mode allows you to change, enable and disable certain features. To enter into settings mode, make sure the touchpad is **POWERED OFF**. Then press and hold the **SMALL** and **MEDIUM** buttons at the same time. Settings mode is enabled when all three size LEDs are lit at the same time.

HOLD AT SAME TIME **S** **M** → **S** **M** **L**




8 CHANGE DEFAULT SIZE

Enter settings mode, then press: Small (3x) **S**

The current default size indicator light will be lit solid. The others will blink. Select from the blinking sizes which one you wish to be your default pour size.

To turn off default size mode so the size stays on whichever size was poured last, press the size button that is currently the default size and it will disable the feature.



9 LED LIGHTS (BRIGHT OR DIM)

The light on the selected size blinks at the rate that the flow meter ticks past the sensor. The light **will not** illuminate unless flow is sensed.

While the touchpad is **TURNED ON**
HOLD the **SMALL** size button then
PRESS the **LARGE** size button to
change between bright and dim LEDs

