



Bottoms Up 3 Button TOUCHPAD V1

HOW TO PROGRAM YOUR TAPS

1 TURN ON THE TOUCHPAD


ON: Press the **L** size button.
An LED will lite up.



2 PRESS & HOLD THE MEDIUM BUTTON

Press and hold the **M** size button.

Note: The default pour size on all touchpads is set to medium and should be used to program your most common pour size. i.e 16oz pints.



3 WHILE HOLDING, PLACE YOUR VESSEL ON THE TAP

While holding the **M** size button, place your vessel down onto the tap. Beer will automatically start to flow.



4 CONTINUE TO HOLD UNTIL FILL LEVEL IS REACHED

Continue to hold the **M** medium button until the desired fill level is reached.

**If you lift finger off too soon, you can press it again and continue filling*



5 WHEN FULL, LET GO AND YOU'RE DONE!

Once the desired fill level is reached, let go and you're done! Your tap is now programmed to pour the exact amount each and every time.

